






All Surface Christmas LED Tree 150/200/300 CM


Assembly instructions - Opbouw instructies - Aufbauanleitung - Instructions de construction



1



2




3






All Surface Christmas LED Tree 150/200/300 CM


Assembly instructions - Opbouw instructies - Aufbauanleitung - Instructions de construction




4



5



6



7



IMPORTANT

- EN** Lower the tree at wind force 6 or higher
- NL** Fairybell® laten zakken bij windkracht 6 of hoger
- DE** Holen Sie den Baum ab Windstärke 6 rein oder bauen Sie ihn ab
- IT** Smontate (nonmontate) l'Outdoor Christmas tree con vento forza 6 o superiore

SPARE PARTS / ONDERDELEN / ERSATZTEILE / RICAMBI

You can easily replace all parts yourself. Visit our website for original spare parts
Alle onderdelen zijn zelf eenvoudig te vervangen. Bezoek onze website voor onderdelen
Sie können problemlos alle Teile selber austauschen. Alle Original-Ersatzteile finden Sie auf unserer Website
Tutti i ricambi sono facilmente sostituibili. Visitate il nostro sito internet per i ricambi originali



For more information:

www.fairybell.eu/service
www.fairybell.us/service